







0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100




Steuertrafo prim.


Steuertrafo sek.




Krümmerwinde




Gelenkwinde




Kopfkran




Ein




Aus



oben



unten



mitte

Thermofühler

E.S. Krümerschützen Verriegelung

E.S. Krümmerwinde

KLAPP - HOPPER - SAUGER  
K E T O  
SEITENSAUGROHRSTEUERUNG  
THERMOFÜHLER- ENDSCHALTER STB

ÄNDERUNGEN	DATUM	NAME
a		
b		
c		
d		
e		
f		
g		

**zoller**  
Uwe E. Zoller GmbH & Co. KG  
Otto-Hahn-Straße 9  
2200 Elmehorn  
Telefon (041 21) 710 51  
Telex 218 386 zol d

Komm.	Mafstab	Zählungs-Nr	Blatt
S-13955	NB 311	S82-1661.75	3